

Care and Maintenance:

- *Our steel components for garden accessories and furniture are treated with rust inhibiting paint that protects it from rusting. However, due to the nature of steel, surface oxidation (rusting) will occur once these protective coatings are scratched. This is not a defect and thus not covered by the warranty.
- *To minimize this condition, we recommend care when assembling & handling the product to prevent scratching the paint. Should any scratching or damage occur, we recommend immediate touch-up with rust inhibiting paint.
- *Surface rust can also be easily removed with a very light application of common cooking oil. If surface oxidation (rusting) occurs and if no measure is taken to prevent this, the oxidation may start dripping on to deck or patio and caused damaging stains, which may be difficult to remove. This can be prevented if the above-mentioned measures are taken to keep the product from oxidizing.
- *Use damp cloth to wipe off the stains as quickly as possible.
- *If necessary, wash with a mild solution of soap and water; rinse thoroughly and dry completely.
- *Periodically check and ensure that all bolts are well-tighten during use
- *Do not leave the gazebo where there is a risk of high wind, as possible damage will occur to the structure. Remove all excess snow from the roof.

